



Push button switches

Push button switches (Illuminated)

Selector switches

Double push button switches

Start push button switches

Emergency switches

Emergency switches (Illuminated)

Pilot lamps

Accessory

Magnetic buzzers

Piezo buzzers

Sockets

Digital switches

<b>S</b>	<b>2</b>	<b>BR</b>	-	<b>P1</b>	<b>G</b>	<b>A</b>
①	②	③		④	⑤	⑥

Classification	Ordering information						Description
	①	②	③	-	④	⑤	
Model	S						Control Switches
Dimension		2					Ø22/25
Appearance			BR				Start push button Switches
Operation					P1		Spring return type, Illuminated
Color					G		GREEN
					R		RED
Contact						A	A (Normal Open) 110VAC/10A, 220VAC/5A
						B	B (Normal Close) 110VAC/10A, 220VAC/5A



● Ø Start push button switches (Non-Flush)

launching soon



Model	Contacts	
	A contact	B contact
S2BR - P1□A	1EA	
" - " □2A	2EA	
" - " □3A	3EA	
" - " □B		1EA
" - " □2B		2EA
" - " □3B		3EA
" - " □AB	1EA	1EA
" - " □2AB	2EA	1EA
" - " □A2B	1EA	2EA

※ Represents colors □ : R, G



- Mushroom-head shaped design
- Mounting hole layout : Ø22.5 / 25.5mm

